



GV = IC package SOT753
 HC or HCT ok.

Solder pad length 2.5mm – 3.0mm.
 3 pins with 0.95mm pin spacing.
 Mount header pins to use it as a
 T0220 or T092 package.

Can be built using common through-hole
 parts. In this case use a 74HCT14. Wire pin
 7 to GND, pin 14 to VCC, pin 1 to C1 and
 pin 2 to point where reset signal is required.

RESET CIRCUIT TO REPLACE DS1233 ECONORESET IC

Reverse-
 Engineered
 By:

GURU
<https://gurudumps.otenko.com>

Date: 23/04/2024 4:36 PM

Sheet: 1/1

REV: A